TOP AND CABINET PARTS

For Models: LSN2000PW4, LSN2000PG4
(White/Grey) (Biscuit/Gold)

AUTOMATIC
WASHER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CABINET PARTS

For Models: LSN2000PW4, LSN2000PG4
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	3958075	Installation Instructions
	8578232	Use & Care Guide
	3955907	Feature Sheet
	3957352	Energy Guide
	8566206	Wiring Diagram

Following May Be Purchased

DO−IT−YOURSELF REPAIR MANUALS

	4313896	Manual, Washer
2		Top
	8543451	White
	8543452	Biscuit
3	62750	Spacer, Cabinet To Top (4)
4	357213	Nut, Push−In (2)
5		Cabinet
	63424	White
	3954357	Biscuit
6	62780	Clip, Top & Cabinet & Rear Panel (2)
7	3976348	Cabinet−Sound Damper (3)
8	3351614	Screw, Ground
9	3357011	Screw, 10−16 x 1/2
10	9724509	Bumper, Lid (2)
11	8318084	Switch, Lid
12	21097	Pad, Hinge (2)
13	355274	Screw, Lid Hinge Mounting (4)
15	8559336	Hinge, Lid (L.H.)
16	91770	Hinge, Lid (R.H.)
18	8319539	Bearing, Lid Hinge (2)
19		Lid
	8558398	White
	8558399	Biscuit
28	3390631	Screw, 10−16 x 3/8 (4)
31	3955788	Cover, Dispenser
32	8519517	Dispenser, Bleach

CONTROLS AND REAR PANEL PARTS

For Models: LSN2000PW4, LSN2000PG4
(White/Grey) (Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROLS AND REAR PANEL PARTS

For Models: LSN2000PW4, LSN2000PG4
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1	3976300	Washer, Water Inlet Hose (4) (1−1/16 x 5/8)
2	694419	Mini−Buzzer
3		Hose, Water Inlet (2)
	8571377	Blue Coupler
	8571378	Red Coupler
4	3400073	Screw, Ground
5	8568314	Strap, Console (2)
6	8318015	Panel, Rear
7	62747	Pad, Rear Panel
8	8559373	Drain Hose Assembly (Includes Items 27 & 33)
9	8541270	Timer, Control (60 Hz.) (Motor Not A Service Part)
10	3351614	Screw, Ground
11	90767	Screw, 8−18 x 3/8
12	3366846	Switch, Water Level
13	8544893	Bracket, Control
14	661661	Cord, Power (Includes Item 15)
15	3952821	Strain Relief, Power Cord
16		Cap, End (L.H.)
	8271365	White
	8271368	Biscuit
17	8317975	Retainer, Harness
18	3979347	Valve, Water Inlet & Thermistor Assy.
19	303294	Edge Protector
20	8318046	Clip, Capacitor
21	301958	Clamp, Hose
22	8055003	Clip, Harness & Pressure Hose
23	370450	Clamp, Hose
24	387606	Break, Vacuum
26	8519200	Support, Rear Panel
27	8541667	Clamp, Hose
28	8572718	Capacitor, Motor Start
30	3363366	Clamp, Hose
31	8317496	Clamp, Hose
32	3951449	Hose, Pump To Tub (Includes #30)
33	8541668	Clamp, Hose
34	3949180	Switch, Rotary
35	62863	Screw, 10−16 x 3/8
36	3400818	Screw, Timer Mounting
37	8536939	Clip, Knob
38	8564140	Switch, Water Temperature (ATC)
39		Panel, Console (Includes Item 52)
	3956592	Silver
	3956593	Gold
40	3949188	Switch, Rotary
41	8541669	Bucket, Drain Hose (Left Half)
42	8541658	Bucket, Drain Hose (Right Half)
43	8317974	Hose, Vacuum Break
44		Knob, Timer
	8544945	Silver
	8544946	Biscuit
45		Dial, Timer
	8544947	White
	8544948	Biscuit
46		Knob, Control
	8544937	Silver
	8544938	Biscuit
49	388326	Screw, 8−18 x 1.25 (Panel to Top)
50	9740848	Screw, 8−18 x 1/2
51		Cap, End (R.H.)
	8271359	White
	8271362	Biscuit
52	3400985	Medallion
53	8541672	U−Bend, Drain Hose
54	3347868	Cable Tie
55	8539874	Shield, Suds
56	3957276	Harness, Wiring (For Detail See Pages 9 & 10)

FOLLOWING PARTS NOT ILLUSTRATED

3957361	Miscellaneous Parts Bag

AGITATOR, BASKET AND TUB PARTS

For Models: LSN2000PW4, LSN2000PG4
(White/Grey) (Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AGITATOR, BASKET AND TUB PARTS

For Models: LSN2000PW4, LSN2000PG4
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1	63580	Dispenser
2	358237	Screw & Washer (5/16−24 x 1)
3	3363003	Clothes Mover
4	3951632	Agitator
5	8528150	Tub Ring & Gasket
6	3976308	Seal, Tub Ring
7	3354845	Clip, Agitator
8	8543666	Washer, Agitator
9	3951682	Cam, Driven
10	3366877	Dog, Agitator Clutch (4)
11	3952374	Bearing−Driven Cam
12	21366	Nut, Spanner
13	8526016	Basket & Balance Ring
15	8519788	Balance Ring
16	63849	Tub
17	389140	Block, Basket Drive
18	383727	Gasket, Centerpost
19	3347780	Hose, Pressure Switch
20	2219077	Clip, Pressure Switch Hose
21	3951744	Agitator (Complete)
22	3951608	Spacer, Thrust
23	3354733	Cap, Barrier
24	3348855	Seal, Inner Cap
26	3949550	Washer

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Models: LSN2000PW4, LSN2000PG4
(White/Grey) (Biscuit/Gold)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake & Drive Tube (Complete) (Refer to Page 11 For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3951311	Clutch (Complete)
6	3951308	Band & Lining, Clutch (Includes Illus. 7 & 8)
7	62646	Cap, Clutch Spring (2)
8	3946792	Spring, Clutch
9	3360630	Gearcase (Complete) (Refer To Page 12 For Further Breakdown)

Illus. No.	Part No.	DESCRIPTION
10	3357334	Screw, Gearcase To Base (3)
11	62611	Plate, Motor Mount To Gearcase
12	62691	Grommet, Motor (4)
13	285753	Coupling, Motor & Isolation
14	8577374	Seal
15	3355454	Clip, Anti−Rattle
16	3400516	Screw
17	3349637	Retainer, Motor (2)
18	3362089	Shield, Tub To Motor
19	8529935	Motor, Main Drive
20	8529896	Switch, Main Drive Motor
21	8546127	Retainer, Pump (2)
22	3363394	Pump (Complete)
23	3387485	Screw, 10−16 x 5/8
24	3946532	Shield, Motor

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MACHINE BASE PARTS

For Models: LSN2000PW4, LSN2000PG4
(White/Grey) (Biscuit/Gold)



Illus. No.	Part No.	DESCRIPTION
1	3400076	Screw, Bracket Mounting (10−32 x 5/8)
2	64067	Bracket, Spring Outer (2)
3	63907	Spring Suspension,(3)
4	8575214	Support & Brake, Tub
5	64065	Bracket, Spring Outer (L.F.)
6	63466	Link, Leveling Mechanism (2)
7	62597	Spring, Leveling Mechanism
8	62837	Pin, Knurled
9	62596	Foot, Rear (2)
13	3347047	Bearing, Centerpost (2)
14	357409	Seal, Centerpost (3)
15	8318050	Spring, Counterweight
16	62568	Pad, Plate
17	3946509	Plate, Suspension (Includes Illus. 16)
18	3363660	Pad, Base
19	3946512	Base Assembly (Includes Illus, 6, 7, 8, 9,16,17,18, & 26.)
21	3359452	Nut, Lock (2) (3/8−16)
22	389102	Foot, Front (2)
23	8577376	Seal, Centerpost
24	285203	Centerpost Bearing Kit (Includes Illus. 13, 14 & 23)
25	63134	Ring, Sound Deadening
26	63806	Retainer, Suspension Spring

WIRING HARNESS PARTS

For Models: LSN2000PW4, LSN2000PG4
(White/Grey) (Biscuit/Gold)



WH2I

WIRING HARNESS PARTS

For Models: LSN2000PW4, LSN2000PG4
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1	3349557	Clip, Harness
2	388498	Clip, Harness
3	3347812	Clip, Harness
4	3352501	Clip, Harness
5	90016	Clip, Harness
6	3390496	Clip, Harness
7	389379	Retainer, (Suds Models)
8		Timer, Block Disconnect
	3948614	White
	352089	Black
9	62889	Receptacle, Terminal (3−Way) (Lid Switch) (Use Term.94613) Or 94614.)
10	353424	Plug, Terminal (3−Way) (Power Cord) (Use Term.94613)
11	62505	Block, Disconnect (Motor 2 Speed) (Use Term.352088)
12	3347243	Block, Disconnect (Use Term. 352088)
13	63523	Protector
14	717252	Connector (2−Way) (Use Term.94614)
15	3352944	Clip, Harness
16	3390423	Block, Disconnect (12−Way) (Timer) (Use Term. 94613)
17	3347730	Receptacle (6−Way) (Use Term. 94613)
18	3349494	Connector, Etc
19	3407125	E.T.C. Control
20	3948617	Connector (T.P.A.) (3−Circuit) (Lid Switch)
21	3360056	Connector (T.P.A) (3−Circuit) (Pressure Switch)
22		Block, Connector
	3354925	Cold Valve
	3354926	Hot Valve

FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

WH2I

BRAKE AND DRIVE TUBE PARTS

For Models: LSN2000PW4, LSN2000PG4
(White/Grey) (Biscuit/Gold)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	356427	Seal, Drive Tube
4	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
5	64035	Ring, Retaining
6	64232	Shoe, Brake (2)
7	62703	"T" Bearing, Spin Tube
8	3353956	Cap, Brake Spring (2)
9	387806	Spring, Brake
10	3355360	Sleeve, Brake Spring
11	661516	Cam, Brake Release
12	63022	Sleeve, Cam
13	64194	Driver, Brake Cam
14	90368	Ring, Retaining

FOLLOWING PARTS NOT ILLUSTRATED

	285208	Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

GEARCASE PARTS

For Models: LSN2000PW4, LSN2000PG4
(White/Grey) (Biscuit/Gold)



Illus. No.	Part No.	DESCRIPTION
1	3360630	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 and 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 and 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389230	Bottom and Pinion, Gearcase
21	285352	Seal, Thrust Plug
22	3351614	Screw, Gearcase Cover, Mounting (8) (10−24 x 3/8)
23	3362552	Ring, Retaining
24	285735	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	3349296	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WATER SYSTEM PARTS

For Models: LSN2000PW4, LSN2000PG4
(White/Grey) (Biscuit/Gold)



Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6	65349	Clamp, Hose
7	367031	Drain Protector (Not Included)

OPTIONAL PARTS (NOT INCLUDED)

For Models: LSN2000PW4, LSN2000PG4
(White/Grey) (Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	4392899	Biscuit
		PAINT, PRESSURIZED SPRAY (12 oz.)
	350938	Primer, Gray
	350930	White
	4392901	Biscuit
		PAINT, BULK (1 qt.)
	799344	White (Uncut)
	4392900	Biscuit (Uncut)
		OIL
	350572	Oil, Gearcase (16 Oz.)
		LUBRICANT
	285208	Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)
		SEALER
	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
		ACCESSORY PARTS
	367031	Drain Protector
	285320	Siphon Break Kit